



**Comfort Zone®** is a blanket, towel, and robe warming system.

#### **Return Policy.**

For a period not to exceed thirty (30) days from the date of purchase, Buyer shall have the right to return the Comfort Zone® for a full refund, less shipping and handling; provided that the Comfort Zone® is returned in its original packaging, includes all accessories and is in its original condition and has not been tampered with or altered in any way.

Ship Returns to:  
Life-Gear, LLC  
1987 South Park Rd.  
Louisville, KY 40219

#### **Warranty.**

For a period not to exceed three hundred and sixty five (365) days from the date of purchase, Life Gear warrants that the Comfort Zone® shall be free of defects in material and workmanship under normal use and service and shall comply with all applicable federal regulations. This warranty shall be void to the extent the Comfort Zone®, or any part thereof, has been tampered with or altered in any way, or has been subject to misuse, negligence, or accident. Correction of any defects which are the responsibility of Life Gear shall be made at Life Gear's facilities, with all freight charges in connection with such repairs to be absorbed by Life Gear. Buyer's sole remedy for any breach of this warranty shall be replacement or repair of the defective Comfort Zone® pursuant to the terms of the preceding sentences. In no event shall Life Gear be liable for consequential and/or special damages in connection with any breach of this warranty. THIS WARRANTY IS EXPRESSLY IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.



another great product from

**LIFE-GEAR, LLC**

TOLL FREE (800) 358-7150

P.O. Box 1132

Prospect, KY 40059

[www.blanketwarmingssystem.com](http://www.blanketwarmingssystem.com)



Comfort Zone® is a blanket, towel, and robe warming system.

CAUTION: To avoid risk of electric shock or fire, keep all liquids or flammable fluids out of unit.

CAUTION: Interior of Comfort Zone® is electrically heated. Comfort Zone® is only suitable for warming cotton or cotton blend textiles. Do not attempt to warm liquids, food items, or other articles of clothing. Hot metal plate inside unit could burn skin or melt plastic. DO NOT place items which have plastic or metal components inside unit.

DO NOT try to disassemble, modify, or repair Comfort Zone®. There are no user-serviceable parts. Contact Life Gear if you have any problems with the unit. For safety and to extend the life of the product, turn off and unplug Comfort Zone® when not in use.

#### **INSTRUCTIONS FOR USE**

1. Remove cord and blankets, towels, or robes from interior of Comfort Zone®.
2. Remove blankets, towels, or robes from plastic. Wash blankets, towels, or robes before first use.
3. Securely plug cord into Comfort Zone® and outlet. The unit is only rated for indoor use.
4. Place blankets, towels, or robes in Comfort Zone®. Make certain that any items placed in Comfort Zone® are unadorned and do not have metal or plastic components. Do not attempt to warm other items or you could damage the unit.
5. Close the Comfort Zone® and securely close fasteners on front of unit. Comfort Zone® automatically shuts off if unit is open.
6. Push red switch on side of Comfort Zone®. Light will turn on, showing that unit is receiving power.
7. If Comfort Zone® is cold, two blankets, two towels, or two robes will heat to maximum temperature in approximately 20 minutes, depending on environmental conditions. If Comfort Zone® is already warm, heating time will be shorter.
8. For fastest heating, use only one blanket, towel, or robe. Leave blanket, towel, or robe in Comfort Zone® for 5 minutes. Remove blanket, towel, or robe and refold to expose un-heated portions. Place blanket, towel, or robe back in Comfort Zone® for 5 minutes to complete heating.
9. After use, push red switch on side of Comfort Zone® to turn unit off (light will turn off).

#### **CLEANING**

1. Turn off and unplug unit and allow to cool completely.
2. Wipe interior and exterior of unit with dry or damp cloth.
3. Allow unit to dry completely before next use.